Recovery Tow Point RP2400 Fitment Guide

Nissan Navara D22

Fitted to factory retained nuts on left hand side and right hand side.

Intall one Spacer Plate per point to provide clearance on angled chasis gusset. (The image on right shows the chassis gusset that the Spacer Plates are required for.)



Ensure 2 bolts per tow point are fitted and torqued to recommended settings to ensure tow points meet tested standard.



Bolt Torque Specs			
	8.8	**10.9**	**12.9**
M10	41 - 60 Nm	59 - 85 Nm	65 - 94 Nm
M12	71 - 105 Nm	102 - 150 Nm	114 - 164 Nm
M14	112 - 168 Nm	161 - 240 Nm	182 - 265 Nm
M16	175 - 260 Nm	250 - 371 Nm	282 - 406 Nm

Hardware supplied with RP2400

4 x M12 x 1.25 Bolts
4 x M12 Spring Washers
4 x M12 Flat Washers
2 x 12mm Spacer Plates

Ensure all supplied and specified components are used during the installation of tow points. Failure to do so will significantly reduce the Working Load Limit (WLL) specified for each individual point (3250kgs for Navara D22), which can result in serious injury or death.

RECOMMENDED FOR 4WD SPECIALISTS MECHANICS TO FIT