Recovery Tow Point RP2500 Fitment Guide

Nissan Navara D40
Nissan Pathfinder R51

Fitted to factory retained nuts on the left hand side

The bolts and retained nuts are supplied for the right hand side.

Ensure 2 bolts per tow point are fitted and torqued to recommended settings to ensure tow points meet tested standards.

Can be mounted to front or rear of vehicle.



Bolt Torque Specs			
	8.8	**10.9**	**12.9**
M10	41 - 60 Nm	59 - 85 Nm	65 - 94 Nm
M12	71 - 105 Nm	102 - 150 Nm	114 - 164 Nm
M14	112 - 168 Nm	161 - 240 Nm	182 - 265 Nm
M16	175 - 260 Nm	250 - 371 Nm	282 - 406 Nm

Hardware supplied with RP2500

4 x M12 x 1.25 Bolts
2 x M12 x 1.25 Nuts on wires

Ensure all supplied and specified components are used during the installation of tow points. Failure to do so will significantly reduce the Working Load Limit (WLL) specified for each individual point (3250kgs for Navara D40), which can result in serious injury or death.

RECOMMENDED FOR 4WD SPECIALISTS MECHANICS TO FIT